

## Antique Tractor Pull Rules

### **CLASSES:**

4,000 lbs.	6,000 lbs.	8,000 lbs.
4,500 lbs.	6,500 lbs.	8,500 lbs.
5,000 lbs.	7,000 lbs.	10,500 lbs.
5,500 lbs.	7,500 lbs.	

### **100 lbs. overweight allowed for each class.**

Drivers' meeting 15 minutes prior to start time.

Tractors must be weighed and registered prior to the drivers' meeting.

Minimum age 16 years old with valid driver's license required to pull.

\$30 per hook.

### **RULES:**

#### **Judge's discretion on ALL rules whether expressly stated here or not.**

1. Engine RPM must not exceed 10% over factory RPM setting.
2. Speed limit 4 MPH.
  - a. Speed violations:
    - i. Prior to 75 ft. Result in a warning via horn on sled.
    - ii. After 75 ft. Result in disqualification.
3. No shifting T/As while pulling.
4. MAXIMUM hitch height 18 inches. Must be stationary in all directions.
5. Hitch must be a least 24 inches from the center of the rear axle.
  - a. Operator of tractor must provide twisted clevis or bolt on plow loop with a minimum opening size of 3 inches.
6. Maximum tire size 15.5 x 38 up to and including 7,000 lbs. class.
7. Maximum tire size 18.4 x 38 for 7,500 lbs. class.
  - a. 8,000 lbs. and above may use larger tires.
8. No radial tires and no cut or altered tires
9. Wheel weights and suitcase weights are allowed.
  - a. Weights must be securely fastened to tractor.
  - b. Weights or parts of the tractor that fall off during pull will result in disqualification.
10. Weights may extend out past the rear axle of the tractor but not further than the maximum radius of the rear tire.
11. Front weights allowed.
  - a. Weights and/or weight bracket not to exceed 24 inches past factory frame.
12. All drivers must remain seated with at least one hand on the steering wheel at all times while pulling.

13. All tractors operated in an unsafe manner on or off the track will result in disqualification.
  - a. No aggressive starts.
  - b. Front wheels must not rise off the ground above knee height.
14. All tractors must be stock appearing. Straight pipes and aftermarket air filters allowed.
  - a. All tractors not meeting the below requirements will only be allowed to pull as exhibition.
    - i. No turbos, blowers, or power-adders of any kind.
    - ii. Stock style manifolds only.
    - iii. Stock appearing engine block.
    - iv. No aftermarket engine performance parts.